Maintenance Schedule for Severe Conditions (listed by distance/time)

Use this schedule if your vehicle is MAINLY driven in any of the following Severe Conditions, or normally driven in Canada; otherwise use the Normal Schedule. Service at the indicated distance or time, whichever comes first. Do the items in **A, B, C, D** as required for each distance/time.

3,750 mi/6,000 km/6 mos	Do items in A.
7,500 mi/12,000 km/-	Do items in A, B.
11,250 mi/18,000 km/-	Do items in A.
15,000 mi/24,000 km/1 yr	☐Clean air cleaner element. Do items in A, B, C.
18,750 mi/30,000 km/-	Do items in A.
22,500 mi/36,000 km/1½ yrs	Do items in A, B.
26,250 mi/42,000 km/-	Do items in A.
30,000 mi/48,000 km/2 yrs	Do items in A, B, C, D.
33,750 mi/54,000 km/-	Do items in A.
37,500 mi/60,000 km/2½ yrs	Do items in A, B.
41,250 mi/66,000 km/-	Do items in A.
45,000 mi/72,000 km/3 yrs	☐Replace coolant. ☐Replace brake fluid. ☐Clean air cleaner element. Do items in A, B, C.
48,750 mi/78,000 km/-	Do items in A.
52,500 mi/84,000 km/3½ yrs	Do items in A, B.
56,250 mi/90,000 km/-	Do items in A.
60,000 mi/96,000 km/4 yrs	☐*2Replace timing belt*1, balancer belt*3, inspect water pump*1. Do items in A, B, C, D.
63,750 mi/102,000 km/-	Do items in A.
67,500 mi/108,000 km/4½ yrs	Do items in A, B.
71,250 mi/114,000 km/-	Do items in A.
75,000 mi/120,000 km/5 yrs	☐Replace coolant. ☐Clean air cleaner element. Do items in A, B, C.
78,750 mi/126,000 km/-	Do items in A.

Severe Conditions:

- Driving less than 5 miles (8 km) per trip or, in freezing temperatures, driving less than 10 miles (16 km) per trip.
- Driving in extremely hot (over 90°F/32°C) conditions.
- Extensive idling or long periods of stop-and-go driving.
- Trailer towing, driving with a roof top carrier, or driving in mountainous conditions.
- Driving on muddy, dusty, or de-iced roads.

A	☐Replace engine oil and filter.
B	☐Inspect front and rear brakes. ☐Rotate tires (follow pattern on page 244). ☐Inspect tie rod ends, steering gear box and boots. ☐Inspect suspension components. ☐Inspect driveshaft boots.
C	☐Check parking brake adjustment. ☐Lubricate all hinges, locks and latches with multipurpose grease.

CONTINUED

Maintenance Schedule for Severe Conditions (listed by distance/time)

82,500 mi/132,000 km/5½ yrs	Do items in A, B.
86,250 mi/138,000 km/-	Do items in A.
90,000 mi/144,000 km/6 yrs	☐Replace brake fluid. Do items in A, B, C, D.
93,750 mi/150,000 km/-	Do items in A.
97,500 mi/156,000 km/6½ yrs	Do items in A, B.
101,250 mi/162,000 km/-	Do items in A.
105,000 mi/168,000 km/7 yrs	☐Replace timing belt*1, balancer belt*3, and inspect water pump. ☐Inspect valve clearance. ☐Replace coolant. ☐Check idle speed. ☐Clean air cleaner element. ☐Replace spark plugs (V6 models). Do items in A, B, C.
108,750 mi/174,000 km/-	Do items in A.
112,500 mi/180,000 km/7½ yrs	Do items in A, B.
116,250 mi/186,000 km/-	Do items in A.
120,000 mi/192,000 km/8 yrs	☐Replace timing belt*, *1, balancer belt*3, and inspect water pump. Do items in A, B, C, D.

	☐Inspect brake hoses and lines (including ABS).
	☐Check all fluid levels, condition of fluids, and check for leaks.
	☐Inspect cooling system hoses and connections.
	☐*Inspect exhaust system.
	☐#*Inspect fuel lines and connections.
	☐Check all lights.
	☐Inspect the underbody.
D	☐Replace air cleaner element.
	☐Replace spark plugs (4-cylinder models).
	☐Inspect and adjust drive belts.
	☐Replace transmission fluid.
	☐Replace air conditioning filter*2.

: See information on maintenance and emissions warranty, last column, page 197.

*1 : See Timing Belt on page 240 to determine need for replacement.

*2 : See Air Conditioning Filter on page 239 for information under special conditions.

* 3 : Balancer belt applies to 4-cylinder models only.